

RECTANGULAR BATHTUBS FEET INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

Before you begin

- Caution:** Risk of personal injury or product damage, Cast Iron Baths are heavy, be careful and get help when it comes to lift up the bathtub.
- To ensure that this product is installed correctly, please read the following instructions carefully, before the installation of the feet.
- We strongly advise that the installation shall be done by a qualified plumber.
- Also be sure that your installation conforms to local codes.

Recommended Tools and Materials:

Adjustable wrench, Cardboard sheet and a level.

Feet Installation

- 1 ° Turn the bathtub upside down on a cardboard sheet to avoid any damage to the enamelled surface, this operation needs to be done in a very gentle and careful manner.
- 2 ° Slot the bolts thru the lugs and feet, and afterwards connect the feet to the lugs by means of the nut washer. Note that in first place the nut must be hand tightened.
- 3 ° Now you can adjust the feet to its exact location on the bathtub. When you've reached the greatest concordance between the feet and bath, you must tighten the nut very firmly; at that point you can use an adjustable wrench.
- 4 ° Carefully place the bath in its normal position, and lay a level on the top of the bathtub rim.
- 5 ° All of the feet have levelling bolts on their lower extremity, providing the feet-to-bath contact; you must regulate them in order to obtain the perfect levelling of the bathtub rim.

