

HERITAGE

BATHROOMS

Installation Guide



Models Covered:

Bath Screens

Please keep this booklet for future reference.

Installer: When you have read these instructions, please ensure you leave them with the user.

INTRODUCTION

Thank you for buying a Heritage Product. When you buy a Heritage product, you can be confident that it not only features a beautiful, distinctive, classic design, but that it has also been made to the very highest quality standards.

To ensure that it works to its full potential, it needs to be fitted correctly.

These fitting instructions have been created to give you all of the information you need and, if you need any further help, please do not hesitate to give us a call on: 0330 026 8503.

CONTENTS

INTRODUCTION	2
SAFETY NOTES	3
INSTALLATION	4 - 6
CARING FOR YOUR PRODUCT	7
GUARANTEE	7
NEED HELP?	7



SAFETY NOTES

Please make sure you read these instructions and retain for future use.

All products manufactured by Heritage Bathrooms are safe, providing they are installed and used correctly and also receive maintenance when needed.

Baths, including the connecting water and waste system need to be installed in accordance with and meet the requirements of the Water Supply Regulations 1999 (Water Fittings) and current by-laws. If you are in doubt about your ability to install this product correctly or safely, you should employ the services of an experienced qualified plumber.

This product must not be modified in any way otherwise this will invalidate the guarantee.

Consider the following whilst using power tools:


- Prior to drilling into walls, check there are no hidden electrical cables or wires and there are also no water pipes. These can potentially be found using an electrical or metal detector. You may also need to know some of the schematics of previous installations to determine the suitability and accommodation of the installation.
- Wear the correct PPE, especially ear, eye and hand protection when using power tools. Unplug any mains equipment after use.
- Keep electrical equipment away from sources of water.
- If a blow-lamp is used when plumbing, the flame must be kept well away from the product otherwise damage may occur.

PRODUCT TYPE (sanitaryware/cast iron etc) are very heavy; a lifting aid or second person at minimum will be required to manoeuvre safely.

Do not stand in the bath until the installation has been completed.



INSTALLATION



INSTALLATION

1. Insert the screen side pillar into the wall channel.
2. When the bath has been aligned, mark the position of the wall channel on the wall. Remove the screen, re-align the wall channel and mark the wall channel screw hole positions on the wall.
3. Using a 4mm masonry drill bit, drill 3 x 35mm deep holes in the marked screw positions on the wall.
4. Insert the 3 x wall plugs into the holes. Using a hammer, knock them until they are flush with the wall.
5. Attach the adjustable wall channel to the wall using 3 x 30mm screws supplied.
6. Insert the side panel into the wall channel.
7. Adjust the position of the bath screen assembly until it is level (parallel) with the bath.
8. From inside of the bath screen assembly, make a mark in the wall channel approx. 100mm from the top. **NOTE:** The wall channel design allows for shower screens to be adjusted so that they can be used on wall surfaces that are not vertical. When marking the hole position, please check to ensure that the drilled hole will go through both the wall channel and the side panel.
9. Using a 3.2 Diameter HS Twist drill bit, drill one hole through the upper marked hole position. The hole must be drilled through the wall channel and side pillar until it reaches the centre.



DO NOT DRILL THROUGH BOTH SIDES.


10. Secure the upper section of the wall channel to side pillar by using 1 x inner screw support and 1 x 10mm screw. **(DO NOT OVERTIGHTEN).**
11. Ensuring that the bath screen is still aligned as required, mark the position of the lower bath screen support screw position approx. 100mm from the bottom of the wall channel.
12. Repeat steps 9 and 10 for the lower bath screen support screw position.



INSTALLATION

13. Mark the centre support screw position approx. equal distance between top and bottom screws and repeat steps 9 and 10.
14. Fit the screw caps x 3 onto the inner screw support cups.
15. Fit the bottom water seal x 1 and assemble to the lower edge of the screen (see Fig 2).
16. It is recommended that a bead of silicone is run down the length of the wall channel and around the screen barrel on the outside of the bath screen.
17. If a rail is to be fitted, please ensure that it is fitted to the outside of the bath screen only.

FIGURE 2



CARING FOR YOUR PRODUCT

Heritage products are made from premium materials, with hand polished, PVD, EPD or electroplated finishes.

Your product should be regularly cleaned with warm water, a mild pH-neutral liquid soap, and polished with a soft cloth. Any residues from soap, toiletries etc. should be rinsed off straight after use.

Household bleaches and cleaners contain harsh chemicals and may damage the surface finish. Avoid using abrasive cloths, scouring pads, scrub sponges, steel wool or anything similar.


Some surfaces such as nickel and pewter may be affected by the dye found in some cloths, so it is also important to avoid leaving cloths on surfaces.

GUARANTEE

The confidence we have in the quality of our products and services enables us to offer a free peace-of-mind product guarantee from 2 years up to a lifetime guarantee against any manufacturing faults, with proof of purchase. In addition, our attentive customer service team are available to help solve any problems which may arise quickly and effectively so you can enjoy your bathroom.

To see the specific guarantee for this product, scan the QR Code or visit the following URL:

<https://www.heritagebathrooms.com/service-centre/guarantee>



NEED HELP?

If your product does not function correctly when you first use it, contact your plumber and make sure that it has been installed and commissioned in line with this Installation and User Guide supplied with the product. If this doesn't solve the problem, then please visit <https://www.heritagebathrooms.com/service-centre/help-and-advice> for some helpful hints and tips; or contact Heritage Customer Service on 0330 026 8503 where our expert team of advisors will be able to offer you, or your plumber, help and advice.



HERITAGE[®]

BATHROOMS

We love to see how Heritage products are used so please keep in touch and share pictures of your new bathroom with us.



@heritagebathrooms

If you have any queries, our dedicated customer service teams and products experts are available to help.

Email us enquire@heritagebathrooms.com Call us **0330 026 8503** Website www.heritagebathrooms.com

UK: Heritage Bathrooms, Pooley Hall Drive, Birch Coppice Business Park, Dordon, Tamworth B78 1SG

EU: Masco Europe S.à.r.l., 14 Rue Strachen, 6933 Mensdorf, Luxembourg.